amFilm[®] Screen Protector **Installation & Use For Hinge Method**

03

04



Don't forget to watch the **Installation Video!**



because Technology matters ...

INSTALLATION INSTRUCTIONS

Please follow the steps below to install your new amFilm screen protector.



Ρ

R

E

Ρ

Wash and dry hands to remove oils and dirt.




www.techmatte.com/install



Visit the link or scan the Barcode to view the video.

APPLICATION



Realign protector as needed and place two of the included Hinge Stickers in between rubber bands to secure the protector to the device. Once the stickers are secure, remove the two rubber bands and set aside.

faces up. Repeat screen cleaning

from **PREP**. Holding onto the Step

1 Tab. slowly peel back and

remove the protective, film laver.



Flip the protector over using the hinge, so the STEP 1 TAB now



Carefully, but guickly flip the protector back over, onto the screen of your device. Make sure it is aligned and secured to the screen. Use the squeegee card to remove bubbles if needed.

Make sure NOT to remove the screen protector from the device in this step.

Hold onto the Step 2 Tab and slowly peel back just the corner of the protective, plastic film at a slight angle. Then remove this entire film layer, along with the tape. Use the squeeze card. placed inside of the cloth to remove any last bubbles.



06

05

HELPFUL TIP FOR A BUBBLE-FREE INSTALLATION

Apply Screen Protector in the bathroom after running hot water for a few minutes. The steamy environment will reduce the dust in the air. which can cause unwanted bubbles.

For More useful methods, tips and installation videos, please visit www.techmatte.com/install

