

Damaged or Arrived Broken?

Try our 1-Click Warranty Claim

Go to TechMatte.com/WarrantyClaim

OR

Scan the QR Code Below.



Want More Coverage?

Unlock our Lifetime Warranty

Go to TechMatte.com/Register

OR



TECHmatte

24/7 Customer Support



support@techmatte.com

www.techmatte.com

STAY CONNECTED



@TechMatte



@TechMatte



/TechMatte

amFilm®

Installation Guide

Scan Me



or visit

www.TechMatte.com/install/GLS2


- 1** Wash and dry your hands thoroughly - this helps to remove any oils and dirt.



- 2** Clean your device's screen - use the included cleaning wipe to clean the entire screen. Then use the provided microfiber cleaning cloth to dry the screen.



- 3** Use the dust removal sticker to remove any dust left behind. (Please SKIP this step if applying to Nintendo Switch Products).




*Do not touch the screen again after this step.

- 4** Pull the Step 1 Tab to remove the protective film layer. DO NOT TOUCH THE ADHESIVE SIDE once the protective film layer is removed.




- 5** Ensure that the adhesive side of the screen protector is facing down. Carefully hold the two tabs on either end of the screen protector.




- 6** Align the screen protector with the device. This placement must be precise. Using the tabs, slowly lower the glass protector onto your device.



- 7** Once the glass is in place, gently slide your fingertip across the screen from top to bottom.



- 8** Eliminate any bubbles by firmly pushing bubbles off towards the edges of the glass. Alternatively, lift the corner nearest the bubbles. Set the corner back down and the bubbles should be gone.



- 9** Hold one of the two tabs and slowly peel back the second protective plastic film.

